AKAI

MODEL VS-P120EM MODEL VS-R120EM/EDG

SCHEMATIC DIAGRAMS AND PC BOARDS


TABLE OF CONTENTS

1. SERVO & SYSCON BLOCK DIAGRAM


13. INFORMATION OF ICs

4.	UPERATION AND OTHER PC BOARDS	U
5.	CONNECTION DIAGRAM	7
6.	VS-P120EM, R120EM VIDEO/AUDIO (1/2) SCHEMATIC DIAGRAM	8
7.	VS-R120EDG VIDEO/AUDIO (1/2) SCHEMATIC DIAGRAM	9
8.	OUTPUT/POWER & VIDEO/AUDIO (2/2) SCHEMATIC DIAGRAM	10
9.	VIDEO/AUDIO & OUTPUT/POWER PC BOARDS	11
10.	CONTROL SCHEMATIC DIAGRAM	12
11.	CONTROL PC BOARD	13
12.	RC-V22E/23E REMOTE CONTROL UNIT SCHEMATIC DIAGRAM	14


Use these schematic diagrams and PC boards together with the provided service manual.










REMO-CON PCB B1030C5010 (RC-V23E)





LA7285 (AUDIO SIGNAL REC/PB AMP)












































































ALL ELECTROLYTIC CAPACITORS IN #F/WV ALL DIODES ARE 155131T


PARTS AVERTISSMENT: A ET . ILS INDIQUENT LES COMPOSTANTS CRITIQUES DE SÉCURITÉ, POUR MAINTENIR LE DEGRÉ DE SÉCURITÉ DE L'APPAREIL, NE REMPLACER QUE DES PIÈCES RECOMMANDEES PAR LE FABRICANT VS-P120EM OUTPUT/POWER & VIDEO/AUDIO (2/2) SCHEMATIC DIAGRAM No.6-4 V118104M


G


H












A B C D E

G



F G